

Assembly instruction

1. Fix base plate B on the 3 anchor pins A and clamp between the narrow nuts C, the distance to the upper edge of the thread is 75 mm.
2. Pour the whole completely vertically into the concrete (1000 mm x 300 x 300);
The upper edge of the concrete is the lower edge of the base plate.
ATTENTION: It is essential to observe the tilting direction!
3. Allow concrete to cure properly.
4. Attach the mast to the anchors already cast in place.
5. Attach hinges H, nuts F and rings G
6. Align the mast vertically by tightening the nuts F.
7. Tighten nuts F after a few weeks.



Montagevoorschrift

